


BRA-A7236



*Not shown to scale.

ELECTRIC CONNECTIONS

1

This part of PF frame can be use as hanger.

2

a. Mark pre installation hole position on wall for mounting bracket.
b. Use drill to make hole in wall.

3

Screw mounting bracket to the wall.

4

a. Mark pre installation hole position on wall for mounting bracket.
b. Use drill to make hole in wall.

TOOLS REQUIRED

| | | | |
|-------|------------|--------------|--------|
| | 15/64" | | |
| DRILL | DRILL BITS | MEASURE TAPE | PENCIL |